WIRING INSTRUCTIONS	
RED	Connect to Positive for Activation
BLACK	Connect to Negative for Ground
WHITE	Connect to Negative for Dimming
BLUE	Momentarily Connect to Negative for Pattern Change
****Connect all **BLUE** wires to enable synchronisation****	

WARNING NOTICE
HIGH INTENSITY BRIGHTNESS – DO NOT STARE DIRECTLY INTO LIGHT

PATTERN LIST			
P1	SPLIT – Slow Double Flash *C*	**P12**	FULL – Fast Single Flash *B*
P2	FULL – Slow Double Flash *A*	**P13**	SPLIT – Combination Single + Quad Flash *C*
P3	FULL – Slow Double Flash *B*	**P14**	FULL – Combination Single + Quad Flash *C*
P4	SPLIT – Fast Quad Flash *C*	**P15**	SPLIT – Variable Speed Flash *C*
P5	FULL – Fast Quad Flash *A*	**P16**	FULL – Variable Speed Flash *C*
P6	FULL – Fast Quad Flash *B*	**P17**	SPLIT – Attack Quad Flash *C*
P7	SPLIT – Slow Single Flash *C*	**P18**	SPLIT – Half Steady + Variable Flash *C*
P8	FULL – Slow Single Flash *A*	**P19**	SPLIT – Half Steady + Single Flash *C*
P9	FULL – Slow Single Flash *B*	**P20**	FULL – Steady-On *C*
P10	SPLIT – Fast Single Flash *C*	**P21**	COMBO – Random Cycle Flash *C*
P11	FULL – Fast Single Flash *A*	**P22**	OFF / DEACTIVATE

GROUPING	
SIMULTANEOUS GROUPING	*To Simultaneously flash all your lights together in one group with the same pattern at the same time, select the exact same PATTERN for each light featuring the same group, for example, all **"A"** or all **"B"** or all **"C"**.*
ALTERNATING GROUPING	*To Alternate flash your lights in two separate groups, select **"A" pattern** for your first group of lights, and select **"B" pattern** for your second group but both groups must feature the same PATTERN to allow the two groups to alternate flash.* *"C" group patterns can ONLY flash simultaneously.*

FUNCTION	PROGRAMMING
NEXT PATTERN	Apply BLUE wire to Negative for < **1 Second**
PREVIOUS PATTERN	Apply BLUE wire to Negative for ≥ **2 Seconds**
FACTORY RESET	Apply BLUE wire to Negative for ≥ **4 Seconds**
DEACTIVATE	Apply BLUE wire to Negative for > **5 Seconds**