

# STRIKER-X Dual-Colour L.E.D. Light Bar



STRIKER-X Function(s)	Wire Colour	Special Notes
Main Ground Negative (-)	<b>BLACK (Thick)</b>	Please ensure that adequate grounding is provided to ensure maximum performance & reliability
Main Positive Power (+)	<b>RED (Thick)</b>	Please ensure that this is connected to the battery with a minimum 10A fuse
Activate COLOUR Group 1 (+)	<b>BROWN</b>	Activates all COLOUR Group 1 warning lights
Activate COLOUR Group 2 (+)	<b>PURPLE</b>	Activates all COLOUR Group 2 warning lights
<b>Activate Both COLOUR Groups (+)</b>	<b>Combine BROWN + PURPLE</b>	When both BROWN + PURPLE Wires are activated, both COLOUR groups will alternate
Flash Pattern Selection (+)	<b>BLUE</b>	Momentarily Apply to Positive to Change Flash Patterns (18 User-Selectable Patterns)
Night Dimming Mode (+)	<b>WHITE</b>	Dimming to 70% Brightness for Night Works
Rear Flashing Only (+)	<b>PINK</b>	When this mode is activated, all FRONT + SIDE warning lights will be DISABLED
Disable Rear White Lights (+)	<b>PINK</b>	Only available on AMBER+WHITE or RED+WHITE configured STRIKER-X Light Bars
Steady-On Cruise Mode (+)	<b>YELLOW</b>	Only available on STRIKER-X Light Bars that <b>DO NOT</b> Feature "Super Take-Down" Function
<hr/>		
Right Directional Arrow Mode (+)	<b>ORANGE</b>	Activates RIGHT Directional Arrow Pattern
Left Directional Arrow Mode (+)	<b>GREEN</b>	Activates LEFT Directional Arrow Pattern
Split Directional Arrow Mode (+)	<b>ORANGE + GREEN</b>	When both ORANGE + GREEN Wires are active, Split Directional Arrow Mode will be displayed
<hr/>		
Take-Down Front Lights (+)	<b>GREY</b>	Concentrated FRONT facing work lights
Super Take-Down Front Lights (+)	<b>YELLOW</b>	Only available on AMBER+WHITE or RED+WHITE configured STRIKER-X Light Bars
Right Side Alley Light (+)	<b>BLACK (Thin)</b>	Concentrated RIGHT facing work lights
Left Side Alley Light (+)	<b>RED (Thin)</b>	Concentrated LEFT facing work lights

## WARNING NOTICE

**HIGH INTENSITY BRIGHTNESS – DO NOT STARE DIRECTLY INTO LIGHT**